

Emergency Briefing

LN-PWA

Engine failure or any failure / abnormalities on runway

1. Throttle IDLE
2. Brakes APPLY
3. Maintain direction
4. Notify ATC

Engine failure after take-off with runway remaining

1. Throttle IDLE
2. FULL flaps
3. 65 KIAS
4. Land on remaining runway

Engine failure after take-off with no remaining runway below 1200ft AGL

1. Throttle IDLE
2. 65 KIAS
3. Land straight ahead, make small corrections to avoid obstacles
4. Flaps as required

Engine failure after take-off above 1200ft AGL

1. Throttle IDLE
2. 65 KIAS
3. Turn into wind to land opposite runway (45° bank)
4. Flaps as required